

1







Kit 187001

VOLKSWAGEN California, 4-dr Bus, (T5) 03-15, (T6) 15-24
VOLKSWAGEN Caravelle, 4-dr Bus, (T5) 03-15, (T6) 15-24
VOLKSWAGEN Multivan, 4-dr Bus, (T5) 03-15, (T6) 15-24
VOLKSWAGEN Shuttle, 4-dr Bus, (T5) 03-15, (T6) 15-24
VOLKSWAGEN Transporter, 2-dr Single Cab, (T5) 03-15, (T6) 15-24
VOLKSWAGEN Transporter, 4-dr Double cab, (T5) 03-15, (T6) 15-24
VOLKSWAGEN Transporter, 4-dr Van, (T5) 03-15, (T6) 15-24




ISO 11154-E


This kit is only for vehicles with fixpoint mounting.




1




2





3



4




5




i



A



B



i

