




INSTALLATION INSTRUCTIONS



Skoda Octavia 5dr

SKO-OCT-5-B

Parts List



x2



x2



x1



x2





x6



x2

INSTALLATION INSTRUCTIONS - SKO-OCT-5-B



INSTALLATION INSTRUCTIONS - SKO-OCT-5-B

